

PWC Proflush Model Specific Tip Sheet



Make: Sea-Doo
Model: GTX
Year: 2001
Engine Size: 951 cc 2-stroke
Engine HP: 130

1. Hose Clamp Installation:



Install the hose clamp on the hose that makes a 'T' just inside the aft bulkhead from the flush adapter. This will ensure full flow of flushing fluid through the engine, rather than allowing some of the fluid to by-pass to the exhaust outlet.

2. Connecting to the PWC Proflush:



A quick disconnect (yellow parts) facilitates connection to the factory flush adapter.

Install the connectors and PWC Proflush at the flush port – port side, stern near the jet pump assembly.



3. Process notes:

Flush per PWC Proflush user manual instructions.