

PWC Proflush Model Specific Tip Sheet



Make: Sea-Doo
Model: XP
Year: 1992
Engine Size: 580 cc
Engine HP: 65

1. Hose Clamp Installation:



Install hose clamp on the hose that goes to the exhaust. This hose is found on the starboard side of the ski. Clamp near the aft bulkhead. Do not clamp between the flush hose connector and the engine.

2. Connecting to the PWC Proflush:



Flushing the 1992 XP requires the use off an aftermarket flush kit.

Connect the PWC Proflush to the watercraft as shown.



3. Process notes:

Flush per PWC Proflush user manual instructions.