

PWC Proflush Model Specific Tip Sheet



Make: Kawasaki
Model: SXI750
Year: 1995
Engine Size: 750 cc
Engine HP: 75

1. Hose Clamp Installation:



Install hose clamp on the hose coming from the jet pump. This hose is found on the port side of the ski, near the aft bulkhead.

Clamping this hose keeps the flushing fluid from escaping out the raw water inlet to the engine.

2. Connecting to the PWC Proflush:



The jetski must have a flush kit installed as shown (white hose).

Attach the flush kit adapter hose fitting to the PWC Proflush pressure regulator.

3. Process notes:

Flush per PWC Proflush user manual instructions.