

PWC Proflush Model Specific Tip Sheet



Make: Mercury (Outboard)
Model: 250 EFI
Year: 2000
Engine Size: 3.0 Litre
Engine HP: 250

1. Hose Clamp Installation:

Hose clamp not required.

2. Connecting to the PWC Proflush:



A quick disconnect (yellow parts) facilitates connection to the factory flush adapter.

Install the quick disconnect and PWC Proflush to the factory flush port.



3. Process notes:

Flush with the engine turned off. Connect as shown in step 2, pressurize the PWC Proflush tank, open the shut-off valve, and allow fluid to run through the engine until tank is empty.