

PWC Proflush Model Specific Tip Sheet



Make: Sea-Doo
Model: RXT
Year: 2005
Engine Size: 1494 cc
Engine HP: 215

1. Hose Clamp Installation:

Hose clamp not required.

2. Connecting to the PWC Proflush:



A quick disconnect (yellow parts) facilitates connection to the factory flush port.

Install the quick disconnect and PWC Proflush to the factory flush port located on the aft exterior of the watercraft, on the port side of the jet pump.



3. Process notes:

The engine in this watercraft is fresh water cooled. Flushing is still necessary to protect the heat exchanger and exhaust components that are raw water cooled.